

Thank you for purchasing AUTEL tool. Manufactured to a high standard, our tool will, if used according to these instructions and properly maintained, give you years of trouble-free performance.

## Getting Started




**IMPORTANT:** Before operating or maintaining this unit, please read these instructions carefully. Use this unit correctly and properly. Failure to do so may cause damage and/or personal injury and will void the product warranty.

1



- Scan QR Code to visit our website at [www.autel.com](http://www.autel.com).
- Create an Autel ID

2



- Connect the main cable's adapter to the vehicle's DLC which is generally located under the vehicle dash.
- The device will be automatically powered up and your ML319 is now ready to work.




Please download the **Maxi PC Suite** from

[www.autel.com](http://www.autel.com) > Support & Updates > Firmware & Downloads > Update Client, and install to your Windows-based computer.


## Software Update

1



- Run the **Maxi PC Suite**.
- Connect the tool with the computer using the included USB cable.
- Select **Update Mode** in the tool.

2



- In the Update window, select the appropriate files to install.

For service and support, please contact us.

<http://pro.autel.com> / [www.autel.com](http://www.autel.com) / [support@autel.com](mailto:support@autel.com)  
0086-755-86147779 (China HQ) / 1-855-288-3587/1-855-AUTELUS (North America)  
0049 (0) 61032000522 (Europe) / (+507) 308-7566 (South America) / 03 9480 2978 / +61 476293327 (Australia)